

Customer Information System

ACIS

Manual

ACIS Version	1.0	1.1	1.1	1.2
Zeichn.Nr: / Draw.	4EP100914		Rev 1	
Erstellt / Drawn	Kollegger	Kollegger	Kollegger	Kollegger
Datum / Date:	1998/12/18	1999/11/19	2000/05/10	2000/08/22
Geprüft / Appr.:	Seidl	Seidl	Seidl	Seidl
Datum / Date:	1998/12/18	1999/11/19	2000/05/10	2000/08/22

1	Welcome to ACIS	3
	1.1 Introduction	3
	1.2 Licence agreement	3
	1.3 System requirements	4
	1.4 Starting ACIS	4
2	How to use ACIS	5
	2.1 Open a database	5
	2.2 Workspace overview	5
	2.2.1 "Tree" - Window	6
	2.2.2 "Viewer" window	7
	2.2.3 "Profile" window	9
	2.3 Display of PDF - documents	10
	2.4 Display TIF documents	16
	2.5 Search in a database	18
	2.5.1 Document Contents	18
	2.5.2 Document Profile	20
	2.5.3 Folder Profile	20
	2.5.4 Settings	21
	2.6 Print Documents	22
	2.6.1 Printing "pdf" - files	22
	2.6.2 Printing "tif" – files	24
	2.7 Export of documents	25
	2.8 Launching external viewer	26
3	Help for problems and technical support	27
-	3.1 Use of ACIS Help	27
	3.2 Frequently asked questions	27
	3.3 Technical support for further questions	28

1 Welcome to ACIS

1.1 Introduction

Until 1998, Andritz AG's plant documentation, production manuals and operating manuals were distributed exclusively in the form of hard copies. The multiplicity of the documents and their sheer size mirror the complexity of our plants and systems, and the idea of utilizing new information technologies was only too obvious, because with them, easy access to the documents is ensured for customers and Andritz personnel, both in sales and in design departments.

In an effort to obviate the different proprietary¹ formats, the documents were without exception transformed into PDF or TIF formats. The corresponding "viewers " are installed with the ACIS² Search Program at the different user workplaces. The ACIS Search Program offers additional tools and expedients to find the required information contained in the documentation and to use it. The usable search strategies are shaped according to the operational and maintenance practices of Andritz AG's systems.

1.2 Licence agreement

The contents of this data media is the intellectual property of Andritz AG and protected by copyright. It is entrusted to the recipient for his personal use only, in connection with the contract concluded with Andritz AG. The contents of this data media must not be copied, reproduced, disclosed to Third Parties or used for any purpose other than those expressly agreed to by Andritz AG or one of its affiliates. This applies particularly to any disclosure to our competitors. Unlawful and not agreed use by recipients or Third Parties shall have private law and penal law consequences. Unless otherwise agreed, these data media shall be returned to Andritz AG on request.

Andritz AG makes no representations or warranties with respect to the contents or use of this manual and data media, and specifically disclaims any express or implied warranties of merchantability or fitness for any particular purpose. Further Andritz AG reserves the right to revise this publication and make changes to its content, at any time, without obligation to notify any person or entity of such revisions or changes. Andritz AG disclaims that all items included in this manual will be available on all software revisions. Andritz AG reserves the right to make changes to any and all parts of ACIS software, at any time, without obligation to notify any person or entity of such changes.

Copyright ©1999 Andritz AG, All rights reserved. No part of this publication may be reproduced, photocopied, stored on a retrieval system, or transmitted without the express prior written consent of the publisher.

¹ not standard

² Andritz Customer Information System

1.3 System requirements

The following system requirements apply to ACIS:

Minimum:

- PENTIUM 120 MHz
- 32 MB RAM
- CD-ROM drive
- Microsoft Windows-95/-98/-NT4.0 or higher

Recommended:

- PENTIUM 300 MHz
- 64 MB RAM

1.4 Starting ACIS

For starting ACIS first place ACIS CD in the computer's CD-ROM drive, which causes the following AutoRun ³ menu to be called. If for any reason whatsoever this does not happen automatically, start the "START.bat" file manually on the CD-ROM. With the mouse select one of these four points described in the following:

Users Manual

Opens this document.

- Start ACIS Starts the ACIS database and the Acrobat Reader.
- Andritz Website

This menu item establishes an automatic link to Andritz AG Website, provided the computer has an Internet access.

• Exit

Termination of current menu.

³ Autorun files on CD-ROMs are automatically started when CD is placed in drive.

2 How to use ACIS

2.1 Open a database

	Database Login	×
ACIS		
<u>Eile E</u> dit <u>V</u> iew <u>T</u> ools <u>H</u> elp	Database title: Product Documentation	
🚼 🖹 😭 🦰 Databases 🔽	Password:	_
□	OK Cancel <u>H</u> elp	

To open a data base, use mouse-key to click on the CD symbol in the upper left-hand corner of the monitor. If the data base is protected by a pass-word, you must enter it in the following dialog box.

Note for the ACIS Demo CD: The product documentation password is: "test"

2.2 Workspace overview

An ACIS viewport consists of three interconnected windows. Each window has a different functionality and presents information in a member set with other windows. Manipulation of these windows allows adapting them to special requirements, thus ensuring flexibility in carrying out these activities. The present section contains an overview of these windows.

S Alchemy		
<u>File Edit View D</u> esign <u>T</u> ools <u>H</u>	<u>H</u> elp	
👔 🖹 😭 🚺 flow_sheet 113	638 🔄 🖨 🌡 🔍 🛞 🏘 🕇 🕇 😼	
List of Main Docu	Image: Sector of the sector	

2.2.1 "Tree" - Window



"Contents" pane

"Results" pane

The tree window contains two pane, each with a different data tree.

- "Contents" gives an index of the data base contents
- "Results" presents the results of the search through the index

2.2.2 "Viewer" window

The viewer window allows for three different display options:

- "List View" the contents of a database or a folder is shown as a list, if this data base/folder has been selected in the tree window.
- "Detail View" to obtain more details of the list displayed, activate the "Detail View" Symbol in the Toolbar. Click the right-hand mouse key (as shown on figure) to add new columns or to cancel columns.



List View

Detail View



Thumbnail Viewer

Document Viewer

- **"Thumbnail Viewer"** In the "Thumbnail" mode, the contents of data bases or folders is shown symbolically, This function may be used in documents containing several pages, and it allows displaying several pages simultaneously.
- "Document Viewer" If a document has been activated in the "Tree" window, the contents of the document or drawing is shown by means of the "Document Viewer" (see also Chapter 2.33. and 2.44.)

2.2.3 "Profile" window

Depending on the part of database is carried out, one of the following "Profile" panes with the pertinent information will be shown:

• Database information

5	About ACIS		
	Δ	Andritz Customer Information System Release6 (Build 157)	
	Copyright	© 1998, Information Management Research, Inc.	
		POTLATCH Plant Dokumentation Revision 2 05-11-1999	

• Folder Profile

Folder Profile	
Document Title: General	

• Document profile

el Group: electric_equipment Equipementnumber: 82000	ocument Title: proximity_switch	IG2008-ABOA data_sheet
Equipementnumber: 82000	Supplier: kühnel	Group: electric_equipment
	Index: 68	Equipementnumber: 82000
	index [68	E dalpementation Dei 182000

2.3 Display of PDF - documents

To display a PDF⁴ document, the "Viewer" Window must have been activated and a PDF file marked with the mouse. (See figure)



Then the "Acrobat Reader" is started automatically and the PDF document is shown in the "Viewer" Window with its standard 5 .



⁴ Portable Document Format

⁵ Standard settings are defined when generating the PDF file.



Using the symbols from the tool bar shown, you can manoeuvre through the different pages of the document, choose between different display variants, search for different contents of the document or print any selected page(s).

The functions of the individual symbols are described in the following:

e	Print on	ne or several pages from docume	ent.	
	Display	of document only		
	🗗 🔁	general_erection_work_instruction		
	A B	15 R B @ Q T K 4	> >I 🔶 🗎 🖸	
		Show /Hide Navigation Pane Please reta	in in a safe place for future use.	•
			9	
		Erection Instruc	ctions	-
	1 71%	6 ▼ 🖪 🤇 1 of 49 🕨 🕨 9 in	<	Þ

Display of document and index



Move directly to the selected chapter via index by clicking on the mouse key.





By clicking on a thumbnail the page is instantly displayed.

8

copies the text elements marked into clipboard



Displayed pages can be manually scrolled and "LINKs" are activated by a mouse click.



Zoom in / out

The different functions can be selected by keeping pressed the mouse button.



Marks text, text blocks or graphics.

The different functions can be selected by keeping pressed the mouse button.



goes to first page



goes back one page



goes forward one page



goes to last page







_								
	95%	٠	Ы	1 von 1	⊧	ы	297 × 209,9 mm	

There are three elements in the bottom left-hand corner showing the page number, zoom factor and document size in inches.



By clicking on the appropriate element, the current page, zoom factor and display mode can be changed.



See next page for display mode.

Single Page

∎ ∙	主 🛛 gene	ral_ere	ction_	work_i	nstru	action												$\exists \parallel$
A	∥B <i>8</i>		Ē	୬ [۹ ر	Τq	I	◀		M	٠	•	Ľ	D	ß	酋	ñ	<u>B</u>
																		Þ
																		Ē
							_		_									
						=												
							- 1		_									
																		-
•	25% 🔻	14	2 of	49 I		8,	26 × 1	11,69	in	8,	ব						Γ	

Continuous



Continuous – Facing Pages



2.4 Display TIF documents

To display TIF⁶ documents, the "Viewer" Window must have been activated (same as for PDF documents, and the required TIF file must have been marked with the mouse.



With the TIF Viewer integrated in ACIS the contents of the document are automatically displayed in the "Viewer" Window.

Acis		- 🗆 ×
<u>F</u> ile <u>E</u> dit <u>V</u> iew <u>T</u> ools	Help	
🍰 🛅 😭 📸 1UW102975.	TIF 💽 🎒 🌡 🏘 🖊 🕇 😼 .	
	🕀 🗓 🛏 🏄 📴 1UW102975.TIF	
		^
12	11	
		_
	-	-
	1324	14 x 9360 x 2

Note for the ACIS Demo CD: A good example for a TIF - Document : database "Plant Documentation" folder "04 Aufbau.." document "P+I Schema..".

⁶ tagged imaged format



The symbols of the tool bar shown have similar functions as those of the Acrobat Reader"



move on one page (if document contains several pages)

2.5 Search in a database



For a search run in a database, first click on the "Search" symbol in the ACIS tool bar, which calls up a window containing four different panes.

2.5.1 Document Contents

Search X Document Contents Document Profile Folder Profile Settings Type your query here: Image: Contents Image: Contents Image: Contents What would you like to search? Image: Contents only Image: Contents only Image: Contents only Image: Content profile fields only Image: Contents only Image: Contents only Image: Contents only Image: Content profile fields only Image: Contents only Image: Contents only Image: Contents only Image: Content profile fields only Image: Contents only Image: Contents only Image: Contents only Image: Content profile fields only Image: Contents only Image: Contents only Image: Contents only Image: Content profile fields only Image: Contents only Image: Contents only Image: Contents only Image: Content contents only Image: Content contents only Image: Content contents only Image: Content contents only	A search word can be entered in the "document contents" pane, and look for it both in the document contents and document profiles. Make required settings in the "What would you like to search?" box.
Select where to search: Search <u>G</u> roups: OBRI-DRY <u>Search</u> Cancel <u>Clear</u> <u>H</u> elp	

Now the required search word can be entered in the "Type in your query here:" line. Make sure to use only small characters, because the data base index contains small characters only.

<u>Type your query here:</u>	
acceptance	עוד

If you have multiple databases, be sure to select just the database you actually want to be searched in the field "Search Groups".



Having entered the search word, the search can be started simply by actuating the search button. Then the "search" window will be closed and the outcome listed in the result window.

Note for the ACIS Demo CD: Search for the query "1sf2".

However, there are two additional helpful functions which facilitate searching:

• List of words previously searched

<u>Type your query here:</u>	
=62	J.
=62	۲ <u>۲</u>
11767us	
027ь	
001b	
bags	
actiengesellschaft	
acessories	
abnormal	•

By clicking on the black triangle at the end of the line, all words are listed for which a search run had previously been made are displayed. Any entry in this list can be reactivated and a new search started with a click of the mouse or with the cursor keys.

Data base index

Type your query here:		
gearbox	•]
Search Word	Hits	
ge	13	
ge38	1	
gea	1	
geachtet	1	
geamotorer	1	
gear	33	
gearbox	8	
geardaaksel	1	
geared	7	
gearhus	1	•

This list which comes up when the blue arrow is actuated, shows all entries, from the data bank index which have conformed with the word entered. This is a useful function especially if you do not know the exact word you want to look for (or its spelling), and already on entering it, it is clear whether there is such a word is in the document and whether it is spelled correctly.

These two tools can also be accessed from the "Document Profile" and "Folder Profile" panes.

Note for the ACIS Demo CD: Open the index of the profile "Anlagenkennzeichen".

2.5.2 Document Profile

📲 Search				×
Document Contents	Document Profile	Folder Profile Set	tings	
Document Title:				. ■
Supplier:		💽 🛃 Group		
Index:		Equipemer	ntnumber:	
		R		
				5545
	<u>S</u> earc	h Cancel	Cl <u>e</u> ar	<u>H</u> elp

With this pane, the search is carried out in the profiles; however, in contrast to the "Document Contents" pane, it is possible to precisely define the profiles to be searched.

2.5.3 Folder Profile

📲 Search			X
Document Contents	Document Profile	Folder Profile	Settings
Document Title:			
File Directory:	dad ^{an} generali da da	1468 - 1988 - 1988 - 1988 - 1988 - 1988 - 1988 - 1988 - 1988 - 1988 - 1988 - 1988 - 1988 - 1988 - 1988 - 1988 -	<u>in a sur an a</u> r dhail
	\searrow		
<u>S</u> earch	Cancel	Cl <u>e</u> ar	<u>H</u> elp

The "Folder Profile" pane limits the search to folders

2.5.4 Settings

#R Search	×
Document Contents Document Profile Folder Profile Settings	
I Bank search results	
_ <u>W</u> ord matching	1
Exact Fuzzy	
Boolean operator to use between fields	1
© <u>A</u> ND ⊂ <u>D</u> R	
Search Cancel Cl <u>e</u> ar <u>H</u> elp	

Three options in the "Settings" pane are prone to influencing the search.

- "Rank search results": By activating this function, the search word does not have to be 100% identical with the contents of the database. The percentage of concurrence is indicated in the "Results" Window.
- "Word matching": The control bar, which can be moved between "Exact" and "Fuzzy", determines the required degree of concurrence between the search word and the contents of the document. It is available only if the "Rank search results" have been activated.
- "Boolean operator to use between fields": The logical operator, which can be set here, refers to the relationship between various fields from the "Document Profile" pane.

IMPORTANT Note: Entries in the three panes ("Document Contents".
"Document Profile" and "Folder Profile") are always gated with AND. This
means when a search is initiated from whatever window, entries in all three
windows are taken into account. The "Clear" key also refers to all three
windows.

2.6 Print Documents

First of all, it is only possible to print the actual chosen document.

2.6.1 Printing "pdf" - files



For printing usual pdf-files just click in the reader window the print button. Choose your installed system printer.

For printing a part of a document, you must switch to "marking graphics" (see chapter 2.3 page 13). Make a rectangle over the graphic (or text) with the mouse and click on the print button.



The print range is now "Selected graphic".

Print Range	
O <u>A</u> ll	🗹 Annotati <u>o</u> ns
C Current page	
C Pages from: 1	<u>to:</u> 1

Go on printing as usual.

2.6.2 Printing "tif" - files

If you have opened a tif-file (indicated with an camera as icon), you have just to press the print button as shown in the picture bellow.



It is also possible to print just a part of this document:



Make with the mouse a rectangle and click print.

The print range is now "Selection". Go on printing as usual.

2.7 Export of documents

If you want to export one document of the CD-database, you have at first to select this document (only the actual chosen document can be exported). For exporting now, use the "retrieve" command in the main menu.



Choose now the path where you want to export.

Retrieve Files	
From pulper ST2C-M operating_instructions	
Io d:\temp\pulper st2c-m.pdf	
Options	
 Save to single file, separate using: Eage breaks Blank lines: 	ACIS X
OK Cancel <u>H</u> elp	

Note for the ACIS Demo CD: Export DXF - files from : database "Product Documentation" folder " cad-drawings (DXF - Zeichnungen)".

2.8 Launching external viewer

To view files which can't be shown in the built-in viewer you can open them in their associated program (for example: Windows media player, MS PowerPoint). Therefore click at the filename with the right mouse button and select the menu entry "Launch".

Note for the ACIS Demo CD: Launch the external viewer for "Product Documentation \ presentation environment & process technologies \ Presentation EP PowerPoint", and for

"Product Documentation \ technical description (Maschinenbeschreibung) \ Movie example"

3 Help for problems and technical support

3.1 Use of ACIS Help

ACIS offers a simple and quick access to on-line⁷ Help. All you have to do is select "Help" in the menu bar, which leads you to a subroutine with the following options:

- Contents Shows complete contents of Help.
- Using Help Helps in navigating ACIS Help
- Keyboard Shows keyboard shortcuts

3.2 Frequently asked questions

- If ACIS - CD cannot be read:

Some CD-ROM drives, mostly older ones, have problems reading recorded CDs. To determine whether yours is such a drive, try reading the same CD on a more recent computer. Should you still have problems reading the ACIS CD, it may have been damaged.

- Autorun Menu does not come up when ACIS - CD is placed in the drive

If the ACIS Autorun Menu does not come up after 10 - 20 seconds, the computer Autorun Function has obviously been deactivated. Start ACIS with the "START.bat" file on the CD.

Ask your System Attendant to activate the Autorun Function.

- Error message "Alchemy AuPIPDF.API"

Alchemy	×
AuPIPDF.API (an Adobe Exchange Plugin file created by IMR) is not installed in the Exchange Plugin Directory. This file is required to access PDF documents within Alchemy.	s

<u>Cause 1:</u> This error message can occur in connection with the "Acrobat plug-in" error message. Follow the instructions given under that heading.

<u>Cause 2:</u> You have started Acrobat Reader from your hard disk. In order to display PDF files in the ACIS interface, Acrobat Reader needs the "AuPIPDF.API" file in its list of plug-ins, and if this is not available, the above error

⁷integrated in program

message will appear. Thus, if you started Acrobat Reader from your hard disk (which lacked the file in its plug-in list) before starting ACIS, it is used for displaying the PDF files and the mentioned error message will appear.

<u>Action:</u> Close all PDF Viewers (Acrobat Reader, Acrobat Exchange, etc.) and the ACIS data base. When restarting ACIS, the Acrobat Reader is automatically started from the ACIS CD.

(CD-ROM drive:\Acrobat\READER\ACRORD32.EXE)

- Error message: "File cannot be opened"

*** There is no built-in viewer for this document format. *** You might consider using the Launch Application feature *** to view this document.

If this error message appears, the file in question is not a *.PDF or *.TIF file. This file is not for viewing but for exporting in its original format. You can view these files by an external viewer as described in section 2.8.

- Error message "Incorrect data carrier"

👷 🛛 Syste	m Process - Wrong Volume 🛛 🗙
8	The wrong volume is in the drive. Please insert volume ACIS-DEMO into drive E:.
	Abort Retry Ignore

Always close the ACIS data base before removing the ACIS CD from your CD ROM. As these are started entirely from the CD, the mentioned error message will come up when this data carrier is not available.

The search mask does not contain blue arrows for drop down lists
 The search gives wrong results

•	≣ ↓
-	

If you have multiple databases, be sure to select only the database you actually want to be searched in the field "Search Groups". The arrows of the drop down lists only appear when there is just one database selected.

3.3 Technical support for further questions

For assistance in using ACIS or in relation to the contents, please contact the following address:

Fax: +43 316 / 6902 – 409 E-mail: <u>acis@andritz.com</u>